




+




DCC central control unit



Driving and switching by using your existing legacy DCC digital command station (output voltage of 16V or higher required). Z21 FW V1.22 or higher required.

The direction of communication is always from the legacy command station into the Z21. At any time, you can take over the loco with another throttle (or App) connected to the Z21.

 Please note the power on procedure: first Z21, second legacy command station